



Telit Modules Linux USB Drivers User Guide

1VV0301371 Rev. 3 – 2018-05-07

TELIT
TECHNICAL
DOCUMENTATION

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

NOTICES LIST

While reasonable efforts have been made to assure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. The information in this document has been carefully checked and is believed to be reliable. However, no responsibility is assumed for inaccuracies or omissions. Telit reserves the right to make changes to any products described herein and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Telit does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

It is possible that this publication may contain references to, or information about Telit products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Telit intends to announce such Telit products, programming, or services in your country.

COPYRIGHTS

This instruction manual and the Telit products described in this instruction manual may be, include or describe copyrighted Telit material, such as computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Telit and its licensors contained herein or in the Telit products described in this instruction manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Telit. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit, as arises by operation of law in the sale of a product.

COMPUTER SOFTWARE COPYRIGHTS

The Telit and 3rd Party supplied Software (SW) products described in this instruction manual may include copyrighted Telit and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and other 3rd Party supplied SW certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Telit or other 3rd Party supplied SW computer programs contained in the Telit products described in this instruction manual may not be copied (reverse engineered) or reproduced in any manner without the express written permission of Telit or the 3rd Party SW supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit or other 3rd Party supplied SW, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

USAGE AND DISCLOSURE RESTRICTIONS

I. License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

II. Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

III. High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

IV. Trademarks

TELIT and the Stylized T Logo are registered in Trademark Office. All other product or service names are the property of their respective owners.

V. Third Party Rights

The software may include Third Party Right software. In this case you agree to comply with all terms and conditions imposed on you in respect of such separate software. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License shall apply to the Third Party Right software.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESS OR IMPLIED FROM ANY THIRD PARTIES REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODE"), AND THE USE OF ANY OR ALL THE OTHER CODE IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODE SHALL HAVE ANY LIABILITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODE OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

APPLICABILITY TABLE

PRODUCTS	MINIMUM KERNEL VERSION
■ ■ DE910 SERIES	3.4
■ ■ GE910 SERIES	4.4
■ ■ HE910 SERIES	4.4
■ ■ LE866 SERIES	2.6.39
■ ■ LE910 SERIES	3.18
■ ■ LE910C1 SERIES	4.11
■ ■ LE910D1 SERIES	2.6.39
■ ■ LE910 V2 SERIES	3.12
■ ■ LE920 SERIES	3.18
■ ■ LE920A4 SERIES	4.11
■ ■ LE922A SERIES	4.10
■ ■ LE940A SERIES	4.10
■ ■ LE940B6 SERIES	4.8
■ ■ LM940 SERIES	4.10
■ ■ LM960 SERIES	4.10
■ ■ ME910 SERIES	4.15
■ ■ UE910 SERIES	4.4
■ ■ UL865 SERIES	4.4

CONTENTS

NOTICES LIST	2
COPYRIGHTS	2
COMPUTER SOFTWARE COPYRIGHTS	2
USAGE AND DISCLOSURE RESTRICTIONS	3
I. License Agreements	3
II. Copyrighted Materials	3
III. High Risk Materials	3
IV. Trademarks	3
V. Third Party Rights	3
APPLICABILITY TABLE	4
CONTENTS	5
1. INTRODUCTION	7
1.1. Scope	7
1.2. Audience.....	7
1.3. Contact Information, Support	7
1.4. Text Conventions	8
1.5. Related Documents	9
2. OPERATING SYSTEM SETUP	10
2.1. Summary	10
2.2. USB compositions	10
2.2.1. PIDs and related compositions	10
2.2.2. Driver option	12
2.2.3. Driver qmi_wwan	13
3. USING THE MODEM.....	14
3.1. Using the serial ports	14
3.1.1. Data connection through serial ports.....	14
3.2. Using the network adapter	14
3.2.1. Data connection through the network adapter.....	14
3.3. Using the modem with ModemManager and NetworkManager ...	15
4. FLASHING DEVICES.....	16
4.1. Overview.....	16
4.2. Flashing device: 0x18d1/0xd00d.....	16
4.3. Flashing device: 0x058b/0x0041	16

4.4.	Flashing device: 0x8087/0x0716.....	17
4.5.	Flashing device: 0x8087/0x0801.....	17
5.	TELIT KERNEL COMMITS	18
6.	ADDITIONAL KERNEL COMMITS	20
6.1.	QUIRK DTR.....	20
6.2.	RAW-IP support and general fixes for rmnet.....	20
7.	GLOSSARY AND ACRONYMS	21
8.	DOCUMENT HISTORY	22

1. INTRODUCTION

1.1. Scope

This document explains which Linux kernel drivers should be used for Telit modules listed in the Applicability Table and how Linux devices can be used for typical use cases.

1.2. Audience

This document targets software developers who are using Telit modules listed in the Applicability Table in a Linux environment.

1.3. Contact Information, Support

For general contact, technical support services, technical questions and report documentation errors contact Telit Technical Support at:

- TS-EMEA@telit.com
- TS-AMERICAS@telit.com
- TS-APAC@telit.com
- TS-SRD@telit.com (for Short Range Devices)

Alternatively, use:

<http://www.telit.com/support>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

1.4. Text Conventions



Danger – This information **MUST** be followed or catastrophic equipment failure or bodily injury may occur.



Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.

1.5. Related Documents

- 80455NT11504A - Using NetworkManager with Telit Modems
- 80455NT11505A - Using ModemManager with Telit Modems
- 1VV0301045 - Linux XFP User Guide
- AT Commands Reference Guide of Telit modules listed in the Applicability Table.

2. OPERATING SYSTEM SETUP

2.1. Summary

Telit modules listed in the Applicability Table expose different kinds of devices according to the Product ID (PID) in use. The table below lists the association between the device type and the used kernel driver:

Device type	Kernel driver
Serial port following the CDC-ACM standard	cdc_acm
Serial port (reduced ACM)	option
Network adapter following the CDC-ECM standard	cdc_ether
Network adapter following the CDC-NCM standard	cdc_ncm
Network adapter following Microsoft RNDIS specification	rndis_host
Mobile broadband adapter following CDC-MBIM standard	cdc_mbim
Rmnet mobile broadband adapter	qmi_wwan
Android Debug Bridge (ADB)	N/A (managed at the user space)
Audio device	snd-usb-audio

In order to use a specific device type the related driver should be included in the kernel.



Some drivers can be found starting from a specific kernel version (e.g. cdc_mbim is available since 3.8). If the driver is not supported by the kernel version in use consider upgrading the kernel or backporting the needed patches.

2.2. USB compositions

2.2.1. PIDs and related compositions

The table below lists the currently supported USB compositions in Linux according to the PID:

PID	Composition
0x0021	6 CDC-ACM devices
0x0022	3 CDC-ACM devices
0x0023	6 CDC-ACM devices + 1 CDC-ECM network adapter
0x0032	6 CDC-ACM devices + 1 MBIM adapter
0x0035	6 CDC-ACM devices

0x0036	6 CDC-ACM devices + 1 CDC-NCM network adapter
0x0100	4 CDC-ACM devices + 1 CDC-NCM network adapter
0x1003	3 reduced ACM devices
0x1004	4 reduced ACM devices
0x1005	4 reduced ACM devices
0x1006	3 reduced ACM devices
0x1010	4 reduced ACM devices
0x1012	3 reduced ACM devices
0x1040	5 reduced ACM devices + 1 rmnet adapter + 1 ADB
0x1041	5 reduced ACM devices + 1 MBIM adapter + 1 ADB
0x1042	5 reduced ACM devices + 1 RNDIS network adapter + 1 ADB
0x1043	5 reduced ACM devices + 1 ECM network adapter + 1 ADB
0x1045	5 reduced ACM devices + 1 RNDIS network adapter + 1 ADB + 1 audio device
0x1100	2 reduced ACM devices + 1 rmnet adapter + 1 QDSS device (not supported)
0x1101	3 reduced ACM devices + 1 rmnet adapter
0x1200	5 reduced ACM devices + 1 rmnet adapter + 1 ADB
0x1201	5 reduced ACM devices + 1 rmnet adapter + 1 ADB
0x1206	5 reduced ACM devices + 1 ECM network adapter + 1 ADB
0x1207	2 reduced ACM devices
0x1208	3 reduced ACM devices + 1 ADB
0x1211	1 reduced ACM device + 1 ECM network adapter + 1 ADB
0x1212	1 reduced ACM device + 1 ADB
0x1213	1 reduced ACM device + 1 ECM network adapter
0x1214	2 reduced ACM devices + 1 ECM network adapter + 1 ADB
0x2300	Config. 1: 3 CDC-ACM devices + 1 RNDIS network adapter Config. 2: 3 CDC-ACM devices + 1 ECM network adapter

For additional details on the composition please refer to the software user guide of the module in use.

The command

```
user@pc:~$ lsusb
```

can be used for retrieving the current modem PID

The command

```
user@pc:~$ ifconfig -a
```

can be used to show the network adapter.

Please refer to AT#USBCFG command description of the modem in use for further details about how to change the USB composition.



Not all the serial ports exposed in the composition can be used for AT commands sending: please refer to the proper AT commands User Guide for port arrangement description.

2.2.2. Driver option

When using one of the supported compositions that requires the option driver, if the serial ports are not available it is possible that modem support in option driver has been added in a more recent kernel version than the one in use.

The solution is to upgrade the kernel version in use or backport the needed patch among the ones listed in chapter 5.

It is possible to add runtime support for serial ports. With root privileges, type in a shell:

```
user@pc:~$ modprobe option
```

```
user@pc:~$ echo 1bc7 <PID> > /sys/bus/usb-serial/drivers/option1/new_id
```

where <PID> is the current pid of the modem.



If a composition presents a network adapter make sure that it has been properly recognized before adding runtime support for serial ports.

If a composition presents an ADB device, when adding runtime support for serial ports, it will be recognized as a serial port, preventing it from working properly.

To have the most updated list of Telit PIDs currently supported in option please refer to the [master branch of Linux git repository](#) (drivers/usb/serial/option.c).



If support is needed for a composition not listed among the supported ones please contact customer support with your request.

2.2.3. Driver qmi_wwan

When using one of the supported compositions that requires the qmi_wwan driver, if the network adapter is not available it is possible that modem support in qmi_wwan driver has been added in a more recent kernel version than the one in use.

The solution is to upgrade the kernel version in use or backport the needed patch among the ones listed in chapter 5.

To have the most updated list of Telit PIDs currently supported in qmi_wwan please refer to the [master branch of Linux git repository](#) (drivers/net/usb/qmi_wwan.c).



Composition 0x1201 of LE920A4 and LE910C1 require commit [14cf4a771b3098e431d2677e3533bdd962e478d8](#) for proper working: please see patch in chapter 5.

If macro QMI_QUIRK_SET_DTR is missing add the commit listed in paragraph 6.1.

If the kernel in use has commit [833415a3e781a26fe480a34d45086bdb4fe1e4c0](#), it should be reverted as done in commit [19445816996d1a89682c37685fe95959631d9f32](#).

LE910C1, LE920A4, LE922A, LE940A, LM940, LM960 require also the commits listed in paragraph 6.2.



If support is needed for a composition not listed among the supported ones please contact customer support with your request.

3. USING THE MODEM

3.1. Using the serial ports

According to the driver in use, the following devices are created for serial ports:

Device name	Kernel driver
/dev/ttyACMx	cdc_acm
/dev/ttyUSBx	option

These are normal Linux character devices and support most of the features implemented by the tty layer.

For sending AT commands a terminal emulator like minicom can be used.

When writing code for using these devices please refer to the programming language API related to character devices. As an example, C applications can use the functions exported in the system header files `fcntl.h` and `unistd.h`. Please refer to the related man page for further details.



It is mandatory to have the DTR asserted for receiving an answer after having sent an AT command.

3.1.1. Data connection through serial ports

For creating dial-up connections through serial ports the software `pppd` can be used. Please refer to [pppd official website](#) for further details and updated source code.

3.2. Using the network adapter

If the USB composition in use presents a network adapter and the related driver is properly loaded, a network interface is created.

Shell command `ifconfig` or `ip` can be used for configuring the network interface or retrieving the network interface related details (please refer to the man page of the command for further details).

3.2.1. Data connection through the network adapter

For establishing a data connection through the network interface refer to the instructions in the following table according to the PID in use:

PID	
0x0023, 0x1206	Please refer to AT#ECM and related commands in the AT commands user guide of the modem.
0x0032, 0x1041	mbim-network from project libmbim can be used. Please refer to the project documentation for further details.
0x0036	Please refer to document “ <i>1vv0301246 - NCM Protocol User Guide</i> ”.
0x1040, 0x1200, 0x1201	qmi-network from project libqmi can be used, Please refer to the project documentation for further details.

0x1043	Please refer to AT#ICMCONNECT and related commands in the AT commands user guide of the modem.
0x2300	Configure the modem using AT#NWMODE command: AT#NWMODE=1,1,1 and wait for reboot. Start the dhcp client on the modem network interface.

If a PID is not available in the above table please refer to the AT commands user guide.



LE922A6 MBIM PID 0x1041 requires for proper working commit [7b8076ce8a00d553ae9d3b7eb5f0cc3e63cb16f1](#): please see patch in chapter 5.

3.3. Using the modem with ModemManager and NetworkManager

ModemManager is a D-Bus-activated daemon which controls mobile broadband (2G/3G/4G) devices and connections.

ModemManager provides a unified high level API for communicating with mobile broadband modems, regardless of the protocol used to communicate with the actual device (AT commands, MBIM, QMI).

For managing non AT-based modems ModemManager uses external libraries: freedesktop.org libqmi for QMI-based modems, libmbim for MBIM-based modems.

ModemManager can be used with freedesktop.org NetworkManager for easier network connections management.

NetworkManager is the standard Linux network configuration tool suite. It supports large range of networking setups, from desktop to server and mobile, integrating well with popular desktop environments and server configuration management tools.

NetworkManager provides a complete D-Bus API used to access the NetworkManager daemon. This interface can be used to query network state and the details of network interfaces like current IP addresses or DHCP options. The API can be also used for managing the connections (creation, activation, deactivation...).

NetworkManager uses freedesktop.org ModemManager for mobile broadband device support.

Please refer to documents "**80455NT11505A - Using ModemManager with Telit Modems**" and "**80455NT11504A - Using NetworkManager with Telit Modems**" for further details.

4. FLASHING DEVICES

4.1. Overview

The modems listed in the following table support firmware update through special flashing devices when using Telit lxfp application (for further details please refer to document “[1VV0301045 - Linux XFP User Guide](#)”).

These flashing devices should be bound to a specific driver according to the PID:

Product	Flashing device (VID/PID)	Kernel driver	Flashing device name to be used with lxfp
GE/HE/UE910, UL865	0x058b/0x0041	usb-serial-simple	/dev/ttyUSBx
LE910, LE920, LE920A4, LE922A6, LE940A6, LM940, LM960	0x18d1/0xd00d	option	/dev/ttyUSBx
LE910 V2	0x8087/0x0716	usb-serial-simple	/dev/ttyUSBx
LE940B6	0x8087/0x0801	usb-serial-simple	/dev/ttyUSBx
LE866, LE910D1	0x216F/0x0051	cdc_acm	/dev/ttyACMx

Flashing devices available in GE/HE/UE910, UL865, LE910 V2, LE940B6 and LE866 appear for a few seconds when the modem is turned on: if the flashing application (lxfp) is not running, the flashing device disconnects and the modem proceeds in normal operative mode.

4.2. Flashing device: 0x18d1/0xd00d

For using flashing device 0x18d1/0xd00d with lxfp, it should be added to the Linux kernel option driver.

Retrieve your kernel sources and open source file drivers/usb/serial/option.c

Add to the struct usb_device_id option_ids the following line:

```
{ USB_DEVICE(0x18d1, 0xd00d) }
```

For production systems it is suggested to modify option source code, in order to permanently link the flashing device to the driver.

For testing purposes support could be added at runtime; in a shell with root privileges type:

```
user@pc:~$ modprobe option
user@pc:~$ echo 18d1 d00d > /sys/bus/usb-serial/drivers/option1/new_id
```

4.3. Flashing device: 0x058b/0x0041

Even though the flashing device 0x058b/0x0041 presents as an ACM device, it should be driven by the kernel driver usb-serial-simple. Support for this device is available since kernel version 4.4-rc8.

For previous kernel versions commit [f33a7f72e5fc033dacccb8d4753d7c5c41a4d67b](#) and [a0e80fbd56b4573de997c9a088a33abbc1121400](#) should be backported. Please see chapter 5 for further details.

4.4. Flashing device: 0x8087/0x0716

Support for flashing device 0x8087/0x0716 is available since kernel version 3.12 with driver usb-serial-simple.

For previous kernel version commit [1f9230713af17657f7ed503a12ddd739d0f48089](#) should be backported.

Runtime support can be added with the following steps: with root privileges unload usbserial driver

```
user@pc:~$ rmmod usbserial
```

Load again usbserial with the following line:

```
user@pc:~$ modprobe usbserial vendor=0x8087 product=0x0716
```

4.5. Flashing device: 0x8087/0x0801

Support for flashing device 0x8087/0x0801 is available since kernel version 4.8-rc7 with driver usb-serial-simple.

For previous kernel version commit [f190fd92458da3e869b4e2c6289e2c617490ae53](#) should be backported. Please see chapter 5 for further details.

Runtime support can be added with the following steps: with root privileges unload usbserial driver

```
user@pc:~$ rmmod usbserial
```

Load again usbserial with the following line:

```
user@pc:~$ modprobe usbserial vendor=0x8087 product=0x0801
```

5. TELIT KERNEL COMMITS

Following the kernel commits related to the modems listed in the Applicability Table. Consider backporting them according to the PID in use if not available in your current kernel version.

Summary	Commit	PID	Availability
USB: option driver: adding support for Telit CC864-SINGLE, CC864-DUAL and DE910-DUAL modems	7204cf584836c24b4b06e4ad4a8e6bb8ea84908e	0x1005, 0x1006, 0x1010	3.4-rc1
usb: option driver, add support for Telit UE910v2	d6de486bc22255779bd54b0fceb4c240962bf146	0x1012	3.15-rc2
USB: option: add support for Telit LE920	03eb466f276ceef9dcf023dc5474db02af68aad9	0x1200	3.8-rc7
NET: qmi_wwan: add Telit LE920 support	3d6d7ab5881b1d4431529410b949ba2e946f3b0f	0x1200	3.8-rc7
net: qmi_wwan: add Telit LE920 newer firmware support	905468fa4d54c3e572ed3045cd47cce37780716e	0x1201	3.13-rc1
usb: option: add support for Telit LE910	2d0eb862dd477c3c4f32b201254ca0b40e6f465c	0x1201	3.18-rc3
USB: cdc_acm: Ignore Infineon Flash Loader utility	f33a7f72e5fc033daccbb8d4753d7c5c41a4d67b	VID 0x058b PID 0x0041	4.4-rc5
USB: serial: Another Infineon flash loader USB ID	a0e80fbd56b4573de997c9a088a33abc1121400	VID 0x058b, PID 0x0041	4.4-rc5
USB: serial: option: Adding support for Telit LE922	ff4e2494dc17b173468e1713fdf6237fd8578bc7	0x1042, 0x1043	4.5-rc2
USb: serial: option: add support for Telit LE922 PID 0x1045	5deef5551c77e488922cc4bf4bc76df63be650d0	0x1045	4.5-rc7
net: usb: cdc_ncm: adding Telit LE910 V2 mobile broadband card	79f4223257bfef52b0a26d0d7ad4019e764be6ce	0x0036	4.6-rc2
USB: serial: option: add support for Telit LE910 PID 0x1206	3c0415fa08548e3bc63ef741762664497ab187ed	0x1206	4.8-rc1
USB: serial: option: add support for Telit LE920A4	01d7956b58e644ea0d2e8d9340c5727a8fc39d70	0x1207, 0x1208, 0x1211, 0x1212, 0x1213, 0x1214	4.8-rc3
USB: serial: simple: add support for another Infineon flashloader	f190fd92458da3e869b4e2c6289e2c617490ae53	VID 0x8087, PID 0x0801	4.8-rc7
NET: usb: qmi_wwan: add support for Telit LE922A PID 0x1040	9bd813da24cd49d749911d7fdc0e9ae9a673d746	0x1040	4.9-rc8

NET: usb: cdc_mbim: add quirk for supporting Telit LE922A	7b8076ce8a00d553ae9d3b7eb5f0cc3e63cb16f1	0x1041	4.9
USB: serial: option: add support for Telit LE922A PIDs 0x1040, 0x1041	5b09eff0c379002527ad72ea5ea38f25da8a8650	0x1040, 0x1041	4.10-rc1
net: usb: qmi_wwan: add QMI QUIRK_SET_DTR for Telit PID 0x1201	14cf4a771b3098e431d2677e3533bdd962e478d8	0x1201	4.11-rc7
net: usb: qmi_wwan: add Telit ME910 support	4c54dc0277d0d55a9248c43aebd31858f926a056	0x1100	4.12-rc1
usb: serial: option: add Telit ME910 support	40dd46048c155b8f0683f468c950a1c107f77a7c	0x1100	4.12-rc2
net: usb: qmi_wwan: add Telit ME910 PID 0x1101 support	c647c0d62c82eb3ddf78a0d8b3d58819d9f552aa	0x1101	4.15-rc4
USB: serial: option: add support for Telit ME910 PID 0x1101	08933099e6404f588f81c2050bfec7313e06eeaf	0x1101	4.15-rc6

6. ADDITIONAL KERNEL COMMITS

6.1. QUIRK DTR

QMI_QUIRK_SET_DTR was introduced in kernel version 4.9-rc1, with the following commit:

Commit name	Commit	Availability
qmi_wwan: add support for Quectel EC21 and EC25	9a765881bf3dcd32847d7108cf48cb04a4ed993f	4.9-rc1

6.2. RAW-IP support and general fixes for rmnet

The following commits are needed for having recent rmnet based modems to work properly:

Commit name	Commit	Availability
net: qmi_wwan: MDM9x30 specific power management	93725149794d3d418cf1eddcae60c7b536c5faa1	4.5-rc1
usbnet: allow mini-drivers to consume L2 headers	81e0ce79f2919dbd5f025894d29aa806af8695c7	4.5-rc1
net: qmi_wwan: support "raw IP" mode	32f7adf633b9f99ad5089901bc7ebff57704aaa9	4.5-rc1
net: qmi_wwan: should hold RTNL while changing netdev type	6c730080e663b1d629f8aa89348291fbcdc46cd9	4.5-rc1
net: qmi_wwan: ignore bogus CDC Union descriptors	34a55d5e858e81a20d33fd9490149d6a1058be0c	4.5-rc1

7. GLOSSARY AND ACRONYMS

ACM	Abstract Control Model
ECM	Ethernet Control Model
MBIM	Mobile Broadband Interface Model
NCM	Network Control Model
PPP	Point to Point Protocol
USB	Universal Serial Bus

8. DOCUMENT HISTORY

Revision	Date	Changes
0	2017-04-28	<ul style="list-style-type: none">• First revision
1	2017-11-24	<ul style="list-style-type: none">• Added LE920A4 and LE910C1 composition 0x1201 kernel commit• Added LM940 in Applicability Table• Added reference to commit "cdc-wdm: fix "out-of-sync" due to missing notifications"
2	2018-02-13	<ul style="list-style-type: none">• Added LM960 in Applicability Table• Added ME910 composition 0x1101• Added "Additional Kernel Commits" chapter• Added "Minimum Kernel Version" in Applicability Table
3	2018-05-07	<ul style="list-style-type: none">• Added LE866 flashing device details• Added kernel commit for PID 0x0036• Added LE910D1 in Applicability Table



SUPPORT INQUIRIES

Link to www.telit.com and contact our technical support team for any questions related to technical issues.

www.telit.com



Telit Communications S.p.A.
Via Stazione di Prosecco, 5/B
I-34010 Sgonico (Trieste), Italy

Telit Wireless Solutions Inc.
3131 RDU Center Drive, Suite 135
Morrisville, NC 27560, USA

Telit Wireless Solutions Ltd.
10 Habarzel St.
Tel Aviv 69710, Israel

Telit IoT Platforms LLC
5300 Broken Sound Blvd, Suite 150
Boca Raton, FL 33487, USA

Telit Wireless Solutions Co., Ltd.
8th Fl., Shinyoung Securities Bld.
6, Gukjegeumyung-ro8-gil, Yeongdeungpo-gu
Seoul, 150-884, Korea

Telit Wireless Solutions
Tecnologia e Servicos Ltda
Avenida Paulista, 1776, Room 10.C
01310-921 São Paulo, Brazil

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2016, Telit